



- 144 Servo Motor Thermals Okay
- 145 TVD Module Ready
- 146 XY Extreme Overtravel Okay
- 147 Ultrasonic Head Cover Closed
- 148 Safety Bumpers Okay
- 149 Emergency Stop Buttons Okay
- 150 TVD Module Voltage Okay
- 151 TVD Bleeder Warning
- 152 TVD Temperature Warning
- 153 TVD Mains Contactor Closed
- 154 Console Emergency Stop
- 155 Front Safety Mats Okay
- 156 Rear Safety Mats Okay
- 157 spare
- 158 spare
- 159 spare
- 160 X Home
- 161 U Home
- 162 Y Home
- 163 X+ Limit
- 164 Y- Limit
- 165 X- Limit
- 166 Y+ Limit
- 167 Z Home
- 168 C Home
- 169 A+ Limit
- 170 A- Limit
- 171 A Home
- 172 X+ Limit #2
- 173 X- Limit #2
- 174 X+ Limit with Print Head Down
- 175 spare




- 180 X Home
- 181 U Home
- 182 Y Home
- 183 X+ Limit
- 184 Y- Limit
- 185 X- Limit
- 186 Y+ Limit
- 187 Z Home
- 188 C Home
- 189 A+ Limit
- 190 A- Limit
- 191 A Home
- 192 X+ Limit #2
- 193 X- Limit #2
- 194 X+ Limit with Print Head Down
- 195 spare



- 168 Print Head Up
- 169 Print Head Down
- 170 Ultrasonic Generator Temperature Error
- 171 Ultrasonic Generator Short Circuit Error
- 172 Ultrasonic Generator A-Fuse Error
- 173 Ultrasonic Generator Wobble Error
- 174 spare
- 175 Inkjet Printer Fault
- 176 Vacuum Zone #1
- 177 Vacuum Zone #2
- 178 Vacuum Zone #3
- 179 Vacuum Zone #4
- 180 Vacuum Zone #5
- 181 Vacuum Zone #6
- 182 spare
- 183 C Axis Lockpin Out



- 180 C Axis Tool Alignment
- 181 spare
- 182 C Axis Tool Alignment
- 183 Tool Height Transducer
- 184 Table Mapping Transducer
- 185 spare
- 186 spare
- 187 spare
- 188 spare
- 189 spare
- 190 spare
- 191 spare



- 192 Table Mapping Transducer
- 193 Tool Height Transducer
- 194 C Axis Tool Alignment
- 195 spare
- 196 spare
- 197 spare
- 198 spare
- 199 spare
- 200 spare
- 201 spare
- 202 spare
- 203 spare
- 204 spare
- 205 spare
- 206 spare
- 207 spare
- 208 spare
- 209 spare
- 210 spare
- 211 spare
- 212 spare
- 213 spare
- 214 spare
- 215 spare